

# **Keyboard Installation Instructions**

#### Contents:

(1) Adjustable Keyboard Mechanism

(1) 18" or 21" Track

(1) Platform (may be shipped in separate packaging)

(1) Track Mounting Kit Includes:

(6) #10 x 3/4" mounting screws

(1) Track Cover/Stop

PS Platform

### **Tools Required:**

Drill

.125 Drill Bit

Power Drill

Phillips Screw Driver

Wrench (for AMS/AMT Mouse Platforms)

Allen Wrench (for AMN Mouse Platform)


## COMFORT PLUS PLATFORM Hardware Includes: PP Models (4) #10-24 x 3/4" Pan Head Screw (2) #10-24 Keps Nuts PF Models (4) #10-1/2" Pan Head Screw PP Platform PF Platform PHENOLIC PLATFORMS Hardware Includes: (4) #10-24 x 1/2" Flat Head Screw (4) #10-24 Keps Nuts PC Platform PD Platform **PLN Platform** CLAMPING PLATFORMS Hardware Includes: (4) #10-24 x 5/16" Pan Head Screw (4) #10-24 Keps Nuts PA Platform + Mouse PA Platform Slide Out Mouse SLIDE OUT KEY BOARD PLATFORMS Hardware Includes: (6) #10 x 1/2" Pan Head Screw

**BBP Platform** 


## **Adjustable Keyboard Mechanism Installation Instructions**

#### **INSTALL TRACK**

- PLACE TRACK
  MARK HOLES W/ PENCIL
- PREDRILL HOLES
- MOUNT TRACK USING (4) #10 X 3/4" **MOUNTING SCREWS** NOTE: DO NOT INSTALL FRONT STOP UNTIL MECHANISM INSTALLATION IS COMPLETE



Back



REFER TO REFERENCE DIAGRAM ON REVERSE SIDE FOR PROPER MOUNTING HARDWARE FOR OF YOUR **PLATFORM** 



### **INSTALL MOUSE TRAY TO KEYBOARD** PLATFORM (OPTIONAL)

REFER TO DIAGRAM FOR PROPER INSTALLATION OF YOUR PLATFORM

Tray Models	Mounting Hardware	
Comfort Plus Platforms:MP Ser	(1) #10-24 x 1/2" Pan Head Screw ies (optional)	(3a)
Universal Platforn	n:	
AMS/AMT	(1) 9/16" Nut	(3b)
AMN Series	(1) Allen Screw (1) Allen screw	

NOTE: TENSION ON SWIVEL TILT MODELS CAN BE FIELD ADJUSTED WITH EITHER A PHILIPS HEAD SCREW DRIVER OR ALLEN WRENCH



- SLIDE MECHANISM INTO THE TRACK
   SWIVEL UNIT OUT OF THE WAY AND
- INSTALL FRONT TRACK COVER STOP WITH REMAINING (2) #10 X 3/4" SCREWS

